

Installation Guidelines

for Newline ProFinish™ Tile Tray System

Premade and Custom

The Newline ProFinish™ Tile Tray is simple and easy to install. It can be installed on solid timber, particle board, concrete or slate/tile board.

For more detailed instructions refer to the instructions included with your Newline Tray.

NB. The Newline ProFinish™ Tray is installed after the wall cladding is fixed and must be waterproofed before tiling.

PREPARE THE FLOOR

The floor must be clean, free of dust and is an even, flat surface. Check using a spirit level and, if necessary, use a suitable leveling compound to correct any unevenness or any hollows in the floor. When fitting the tray to timber floors, we recommend the use of a slate and tile underlay, particularly when the wooden floor has been oiled.

FITTING THE NEWLINE PROFINISH™ TRAY

Place the ProFinish™ Tray in position and mark the external perimeter of the tray and the position of the waste hole.

Remove the base and fit the waste outlet to the floor.

Once the plumber has installed the waste, place the ProFinish™ Tray back into position. Use a sharp knife to cut around the outside of the waste until the tray fits neatly around the outer perimeter of the waste flange.

Lift the ProFinish™ Tray and apply the adhesive supplied, as per instructions. Fit back into place and press firmly over the entire surface.

NB. Warranty is void if the adhesive used to fix the tray in position is NOT a brand tested and recommended by Newline.

WATERPROOFING

The ProFinish™ Tray is now ready for waterproofing with your choice of waterproof membrane. Refer to information on tested and approved membranes compatible with the Newline ProFinish™ Tile Tray.

NB . The waterproofing must be applied as per the manufacturer's instructions. Some warranties are invalid if an approved applicator is not used.

Ensure that the waterproofing is applied down into the waste flange and up the inside vertical face of the foam sill, across the top edge and down the floor line on the outside of the ProFinish™ Tray.

Where frameless doors are fitted, it is recommended that floor areas outside the shower should also have the waterproofing membrane applied.

TILING

Your shower is now ready for tiling with your choice of tiles.